


DTF Powder Applicator Control Board



1. Manual Step Increase
2. Manual Powder Increase
3. Manual Powder Decrease
4. Step Auto
5. Powder Auto
6. Manual Step

7. Manual Powder
8. Manual Step Decrease
9. Signal Wire to Powder Box
10. Signal Wire to Step Drive
11. Auto Step Sensors
12. Power In